


Parts Breakdown H3257



REF PART #	DESCRIPTION
1	PH3257001 AIR ADJUSTMENT SCREW
2	PH3257002 AIR ADJUSTMENT KNOB
3	PH3257003 O-RING
4	PH3257004 WASHER
5	PH3257005 AIR VALVE SPRING
6	PH3257006 AIR INLET VALVE
7	PH3257007 SWITCH SPRING
8	PH3257008 AIR VALVE BODY
9	PH3257009 SWITCH KNOB
10	PH3257010 O-RING
11	PH3257011 PLIABLE WASHER
12	PH3257012 DIRECTION SCREW
13	PH3257013 SPRING
14	PH3257014 NUT
15	PH3257015 FLUID CAP WASHER
16	PH3257016 ATOMIZATION CAP
17	PH3257017 FLUID NOZZLE
18	PH3257018 BAFFLE
19	PH3257019 JOINT WASHER
20	PH3257020 DIRECTION SCREW
21	PH3257021 PAINT NEEDLE WASHER
22	PH3257022 LOCKING SPRING
23	PH3257023 TRIGGER LEVER I
24	PH3257024 TRIGGER LEVER II

REF PART #	DESCRIPTION
25	PH3257025 TRIGGER
26	PH3257026 SNAP RETAINER
27	PH3257027 SNAP RETAINER
28	PH3257028 VENTILATOR HEAD
29	PH3257029 CUP LID
30	PH3257030 CUP
31	PH3257031 FILTER
32	PH3257032 FLUID INLET WASHER
33	PH3257033 FLUID INLET JOINT
34	PH3257034 FLUID ADJ. NEEDLE
35	PH3257035 FLUID NEEDLE SPRING
36	PH3257036 JOINT
37	PH3257037 FLUID ADJUSTMENT KNOB
38	PH3257038 PHILLIPS SCREW
39	PH3257039 PATTERN ADJ. KNOB
40	PH3257040 PATTERN ADJ. HUB
41	PH3257041 WASHER
42	PH3257042 PATTERN ADJ. SCREW
43	PH3257043 O-RING
44	PH3257044 SNAP RETAINER
45	PH3257045 AIR INLET JOINT
46	PH3257046 BAFFLE WRENCH
47	PH3257047 SERVICE WRENCH
48	PH3257048 CLEANING BRUSH